



Installation Instructions

HEAT-RECOVERY-UNIT



CWL - 300/400 Excellent

Standards and regulations	3	9	Maintenance	27
Explanation markers	4	9.1	Filter cleaning	27
1 Delivery	6	9.2	Maintenance	28
1.1 Scope of delivery	6	10	Elektric diagrams	30
2 Application	7	10.1	Basic diagram	30
3 Version	8	10.2	Wiring diagram	31
3.1 Technical informtion CWL-300 Excellent	8	11	Elektric connections accessoires	32
3.2 Fan graph CWL-300 Excellent	8	11.1	Connectors	32
3.3 Technical informtion CWL-400 Excellent	9	11.2	Connection examples multiple switch	33
3.4 Fan graph CWL-400 Excellent	9	11.2.1	Multiple switch with filter indication	33
3.5 Connections and dimensions	10	11.2.2	Wireless remote control (without filter indica- tion)	33
3.5.1 CWL-300/400 Excellent Right-hand version ...	10	11.2.3	Additional multiple switch with filter indicati- on	33
3.5.2 CWL-300/400 Excellent Left-hand version	11	11.2.4	Additional multiple switch with wireless re- mote control	33
3.6 Exploded view appliance	12	11.3	Couple CWL-300/400 Excellent through eBus contact; all appliances equal air flow rate	34
4 Operation	13	11.4	Wiring diagram postheater connection or ex- tra preheater	35
4.1 Description	13	11.5	Connection example geo heat exchanger	36
4.2 Bypass conditions	13	11.6	Connecting external switch contact	37
4.3 Frost protection	13	11.7	Connection to 0 - 10V	38
4.4 Version	13	11.8	Connection RH (humidity) - sensor	39
5 Installation	14	12	Service	40
5.1 Installation general	14	12.1	Exploded view	40
5.2 Placing the appliance	14	12.2	Notes	41
5.3 Connecting the condensate discharge	14	13	Setting values	42
5.4 Connecting ducts	14		Declaration of conformity	46
5.5 Electric connections	16			
5.5.1 Connecting the power plug	16			
5.5.2 Connecting the multiple switch	16			
5.5.3 Connecting the eBus connector	16			
6 Display	17			
6.1 General explanation control panel	17			
6.2 Operation mode	18			
6.2.1 Status System fan	18			
6.2.2 Display air flow rate	18			
6.2.3 Message text for operation mode	19			
6.3 Settings menu	20			
6.4 Read out menu	21			
6.5 Service menu	22			
7 Putting into operation	23			
7.1 Switching the appliance on and off	23			
7.2 Setting the airflow rate	24			
7.3 Other settings installer	24			
7.4 Factory setting	24			
8 Fault	25			
8.1 Trouble shooting	25			
8.2 Display codes	25			

Standards

For the Comfort domestic ventilation units of CWL Excellent series, check the following standards and requirements:

- EC Directive 2004/108/EC on the approximation of the laws of Member States relating to electromagnetic compatibility (EMC Directive)
- EC Directive 2006/95/EC relating to electrical equipment designed for use within certain voltage limits (Low Voltage Directive)
- EC Directive 2011/65/EU on the restriction of use of certain hazardous substances in electrical and electronic equipment (RoHS Directive)
- DIN EN 12100/1+2 Safety of machinery; general design principles
- DIN EN ISO 13857 Safety of machinery safety distances
- DIN EN 349 Safety of machinery; minimum gaps
- VDE 0700/500 Safety of electrical appliances for household and similar purposes
- EN 60335/1 Safety of electrical appliances; general requirements
 EN 60730
- EN 6100 Electromagnetic compatibility

For the planning and execution of a controlled ventilation following standards and regulations must be observed:

- | | |
|--------------|--|
| EN 12792 | Ventilation Technology, terminology and symbols |
| DIN EN 13779 | Ventilation Technology; Health Technical Requirements |
| DIN 1946-6 | Ventilation Technology, ventilation of apartments |
| DIN 1946-10 | Ventilation Technology, ventilation of apartments |
| DIN 4719 | Residential ventilation - Requirements, testing and marking of performance ventilation devices |
| DIN 18017-3 | Ventilation of bathrooms and toilet rooms without outside windows with fans |
| DIN EN 832 | Thermal performance of buildings; calculation of heating energy needs - residential building |
| VDI 2071 | Heat recovery ventilation systems |
| VDI 2081 | Noise generation and noise reduction in ventilation systems |
| VDI 2087 | Air duct systems - bases |
| VDI 3801 | Operation of ventilation systems |
| VDI 6022 | Hygienic standards for ventilation systems |
| EnEV | Energy Saving Regulation |

These instructions must be kept available as a part of the unit supplied!
--

General information

These service instructions are only applicable to CWL 300/400 Excellent

Authorised personnel should read these instructions before any commissioning or maintenance work.

Observe the instructions given in this document. Installation, commissioning and maintenance work must only be carried out by trained personnel.

These instructions should be considered an integral part of the unit supplied, and should always be easily accessible.

Failure to observe these installation and service instructions voids any Wolf GmbH warranty.

Reference symbols

The following symbols are used in this instruction manual. This important information concerns personal as well as operational safety."



"Safety instructions" are instructions which you must follow exactly, to prevent risks or injuries to individuals, and damage to the unit.



Danger through 'live' electrical components! Please note: Turn off the ON/OFF switch before removing the casing. Never touch electrical components or contacts when the ON/OFF switch is in the ON position. This would lead to a risk of electrocution that may lead to injury or death. The main supply terminals are 'live' even when the ON/OFF switch is in the OFF position.

Please note

"Please note" designates technical instructions which you must observe to prevent the unit malfunctioning or being damaged.

Safety instructions

Only qualified and trained personnel may be appointed for the installation, commissioning, servicing and operation of the unit.



Electrical installation and repair work on electrical components may only be carried out by qualified electricians.

Only qualified electricians are permitted to work on the electrical system VDE regulations [or local regulations] and those of your local power supply utility are applicable to electrical installation work.

The CWL CWL Excellent ventilation unit must only be operated within the power range that is specified in the technical documentation supplied by the wolf.

Safety and monitoring equipment must not be removed, bypassed or put out of operation in other ways.


Only operate the unit when it is in perfect technical condition. Any faults or damage which impact or might impact upon the safety or correct function of the unit must be remedied immediately by qualified personnel. In this case shut off the appliance immediately to prevent further use.

Intended use

The CWL CWL Excellent ventilation unit is a central ventilation system with integrated heat recovery for ventilation and venting of one or more rooms in apartments and houses.

With this device, the used air is extracted from the kitchen, bathroom and toilet, filtered and removed from the heat transported through the heat exchanger into the open.

At the same time fresh outside air is sucked in, cleaned by an air filter, heated by the heat exchanger and supplied to areas such as living room, bedroom and nursery.


- Determining the proper use** The intended use of the device includes the exclusive use for ventilation purposes.
Only air may be displaced
The unit must only be permitted to handle air. This air must not contain any harmful, combustible, explosive, aggressive, corrosive or otherwise dangerous substances, as these would be distributed throughout the duct system or building, where they could cause a risk to health of, or even kill the occupants, animals or plants living there.
- Exhaust ventilation systems such as Hoods, laboratory extractors, vacuum systems, etc. must not be connected to the device.
These exhaust systems have to be operated separately.
- Installation site** The device may only be installed in a frost-protected area.
The device must be mounted horizontally.
 The site is so determined that sufficient condensate drain can be guaranteed.
The device must not be in the immediate vicinity of flammable liquids and gases, or in places with high humidity (eg swimming pools) or chemical attack aggressively modified installed.
For maintenance, a space of 70 cm in front of the appliance is required.
- Operating instructions** Let instruct you on the operation by which the practitioner is responsible for the installation of the device and its control.
- Do not make any changes to the device.
- Change at longer periods of standstill for hygiene reasons, the filter before being used again.
- In homes with ventilation systems subject to open flue combustion equipment of DIN 1946-6.
- Maintenance** Check the unit periodically for function, damage and dirt.
- During maintenance, disconnect the appliance from the mains and secure it against accidental reconnection.
- Only replace faulty components and equipment with original WOLF spare parts.
Any modification of the appliance and when NOT using original Wolf spare parts, the warranty claim against the company Wolf goes out.
- Disposal** For the disposal of faulty system components or the system and recycling at the end of the product service life, observe the following information: Dispose of all equipment in accordance with applicable regulations, i.e. separate material groups correctly. The aim should be the maximum possible recycling of basic materials with the least environmental impact. Never throw electrical or electronic scrap into the household waste, but recycle it appropriately. Generally, dispose of materials in the most environmentally responsible manner according to environmental, recycling and disposal standards.

1.1 Scope of delivery

Before starting installation of the heat recovery unit, check that it has been supplied complete and undamaged.

The scope of delivery of the heat recovery unit Typ CWL-300/400 Excellent includes the following components:

- ① Heat recovery appliance type CWL-300/400 Excellent
- ② Wall mounting bracket kit containing:
 - 2 x suspension strips
 - 3 x protective caps
 - 1 x rubber strip
 - 2 x rubber rings
 - 1 x mounting instructions
- ③ PVC condensate discharge connection containing:
 - 1 x synthetic screw gland 1.5"
 - 1 x sealing ring
 - 1 x PVC glued coupling 32 mm
- ④ Documentation set consisting:
 - 1 x installation instructions
 - 1 x occupants instructions



The CWL-300/400 Excellent is a ventilation unit with heat recovery with an efficiency of 95%, a maximum ventilation capacity of 300 or 400 m³/h and low-energy fans. Features CWL-300/400 Excellent:

- steplessly adjustable air flow rates through a control panel;
- filter indication on the appliance and the possibility for filter indication on the multiple switch;
- a completely new intelligent frost protection system which ensures that also at low outdoor temperatures the appliance's performance remains optimal and that, if necessary, it activates the standard preheater.
- low sound level
- comes as standard with automatic bypass valve
- constant flow control
- low energy consumption
- high efficiency

The CWL-300/400 Excellent is available in the left-handed or right-handed version. A left-handed version has the filters on the left behind the filter door; a right-handed version has the filters on the right behind the filtered door. The position of the air ducts differs for these two versions! For the correct position of the connection ducts and dimensions see § 3.5.1 or § 3.5.2, respectively.

When ordering an appliance always state the correct type; subsequent conversion to a different version is not possible.

The CWL-300/400 Excellent comes ready to plug in with a 230 V mains plug and a connection for a low-voltage multiple switch on the outside of the appliance.

Note: When replacing a CWL-300/400 by a CWL-300/400 Excellent, do realise that the positions of the ducts "From dwelling" and "From atmosphere" are different! (only for type 4/0 & 3/1) Carefully check the position of these ducts on the basis of the connection drawings §3.5.1 and §3.5.2.

Note: With enterprise of fire places and ventilation systems and/or devices.

Apply the provisions of the relevant district chimney sweep.

This is to be drawn from the planning period to rate.


3.1 Technical information CWL- 300 Excellent

CWL - 300 Excellent				
Supply voltage [V/Hz]	230/50			
Protection degree	IP30			
Dimensions (w x h x d) [mm]	675 x 765 x 564			
Duct diameter [mm]	Ø160			
External diameter condensate discharge [mm]	Ø32			
Weight [kg]	38			
Filter class	G4 (F7 optional for supply)			
Fan setting (factory setting)		1	2	3
Ventilation capacity [m³/h]	50	100	150	225
Permissible resistance ducts system [Pa]	3 - 7	11 - 28	26 - 66	56 - 142
Rated power (excl. preheater)[W]	9,0 - 9,2	13,7 - 15,2	22,0 - 29,2	46,8 - 66,2
Rated current (excl. preheater)[A]	0,104 - 0,107	0,150 - 0,161	0,214 - 0,274	0,403 - 0,578
Max. rated current (with preheater switched on) [A]	6			
Cos φ	0,368 - 0,374	0,391 - 0,416	0,447 - 0,463	0,506

Sound power CWL-300 Excellent									
Ventilation capacity [m³/h]		90		150		210		300	
Sound power level Lw (A))	Static pressure [Pa]]	50	100	50	100	50	100	50	100
	Housing emission [dB(A)	30	33	38	38	44	46	50	52
	Duct "from dwelling" [dB(A)]	33	34	39	42	45	46	54	54
	Duct "to dwelling" [dB(A)]	44	47	52	55	60	60	67	67

In practice, the value may deviate 1 dB(A) as a result of measuring tolerances

3.2 Fan graph CWL-300 Excellent



Note: The value stated in the circle is the capacity per fan (in Watt)


3.3 Technical information CWL-400 Excellent

CWL - 400 Excellent	
Supply voltage [V/Hz]	230/50
Protection degree	IP30
Dimensions (w x h x d) [mm]	675 x 765 x 564
Duct diameter [mm]	Ø180
External diameter condensate discharge [mm]	Ø32
Weight [kg]	38
Filter class	G4 (F7 optional for supply)
Fan setting (factory setting)	1 2 3
Ventilation capacity [m³/h]	50 100 200 300
Permissible resistance ducts system [Pa]	3 - 6 6 - 20 25 - 49 56 - 178
Rated power (excl. preheater)[W]	8,6 9,5 - 15 29 - 40 72 - 98
Rated current (excl. preheater)[A]	0,10 0,12 - 0,14 0,24 - 0,31 0,51 - 0,7
Max. rated current (with preheater switched on) [A]	6
Cos φ	0,38 0,45 - 0,40 0,56 - 0,58 0,60 - 0,61

Sound power CWL-400 Excellent												
Ventilation capacity [m³/h]		100		200		225		300		400		
Sound power level Lw (A)	Static pressure [Pa]	9	40	38	80	47	100	84	175	240	150	225
	Housing emission [dB(A)]	28,5	31,5	39,5	40,5	42,5	46,5	50,0	52,0	53,0	53,5	56,0
	Duct "from dwelling" [dB(A)]	30,5	33,5	45,5	47,0	47,5	49,0	55,5	56,0	57,0	58,0	59,0
	Duct "to dwelling" [dB(A)]	41,5	46,5	56,0	58,0	59,5	61,5	65,0	67,5	68,5	69,5	79,5

In practice, the value may deviate 1 dB(A) as a result of measuring tolerances


3.4 Fan graph CWL-400 Excellent




Note: The value stated in the circle is the capacity per fan (in Watt)

3.5 Connections and dimensions CWL-300/400 Excellent


3.5.1 CWL-300/400 Excellent, right-handed version







CWL-300/400 Excellent Right-handed 2/2




CWL-300/400 Excellent Right-handed 4/0




CWL-400 Excellent Right-handed (no CWL-300 Exc.)

- 1 = To dwelling 
- 2 = To atmosphere 
- 3 = From dwelling 
- 4 = From atmosphere 
- 5 = Electric connections
- 6 = Connection condensate discharge
- 7 = Wall mounting bracket (note the correct position of the rubber strip, washers and caps) (see page 11)


3.5.2 CWL-300/400 Excellent, left-handed version




CWL-300/400 Excellent left-handed 2/2



CWL-300/400 Excellent left-handed 4/0




CWL-400 Excellent left-handed 3/1 (no CWL-300 Exc.)



Mounting wall suspension kit
Extra assembly instructions included with suspension kit.

3.6 Exploded view appliance



1	Service connector	Computer connection for service purposes.
2	Display and 4 control buttons	Interface between user and control electronics.
3	Control board	Contains the control electronics for the basic functions.
4	Extract air filter	Filters air flow from dwelling
5	Preheater	Heats up the outdoor air when there is a risk of freezing for the heat exchanger
6	Heat exchanger	Ensures heat transfer between input and output air
7	Supply air filter	Filters outdoor air supplied to the dwelling
8	Outdoor temperature sensor	Measures outside air temperature.
9	Indoor temperature sensor	Measures the dwelling air temperature
10	Bypass valve	Sends the air through or around the heat exchanger (For the 3/1 and 4/0 this valve is in the upper part of the appliance)
11	Condensate discharge	Connection condensate discharge (Kit comes separately with the appliance)
12	Extract fan	Discharges air from the dwelling to the atmosphere.
13	Supply fan	Feeds fresh air into the dwelling.
14	Modular connector multiple switch X2	Connections for cable to multiple switch, if desired with filter indicator.
15	Connector eBus X1	Connection for eBus control
16	Connector X15	Contains the various control inputs and outputs
17	Connector X14	Connection postheater (accessible after taking off the display cover)
18	Mains cable 230 V	Gland power cable 230 volt
19	Connection to the postheater or to the additional preheater	Gland 230 V cable to postheater or to the additional preheater

4.1 Description

The appliance comes plug and play and operates fully automatically. The extracted indoor air heats up the fresh, clean outdoor air. That saves energy and fresh air is sent to the required rooms.

The control system has three ventilation modes. The air flow rate can be adjusted per ventilation mode. The constant volume control system ensures that the air flow rate of the supply and extract fans is realised independent of the duct pressure.

4.2 Bypass conditions

The standard bypass valve makes it possible to supply fresh outside air that is not heated by the heat exchanger. Particularly during summer nights it is desirable to supply cooler outside air. Then the hot air in the dwelling is replaced by cooler outside air in so far as possible.

The bypass valve opens and closes automatically when a number of conditions are satisfied (refer to the table below for bypass conditions).

The operation of the bypass valve can be adjusted in step number 5, 6 and step number 7 in the settings menu (see chapter 13).

Bypass valve conditions	
Bypass valve open	<ul style="list-style-type: none"> - The outdoor temperature is higher than 10°C and - the outdoor temperature is lower than the indoor temperature in the dwelling and - the temperature in the dwelling is higher than the temperature set at step no. 5 in the settings menu (set standard at 22°C).
Bypass valve closed	<ul style="list-style-type: none"> - The outdoor temperature is lower than 10°C or - the outdoor temperature is higher than the indoor temperature in the dwelling or - the temperature outside the dwelling is lower than the temperature set at step no. 5 in the settings menu minus the set temperature on the hysteresis (step no 6), this temperature is standard set at 20 ° C (22.0 ° C minus 2.0 ° C).

4.3 Frost protection

The unit has an intelligent frost protection.

Function description:

After activation of the frost protection (outdoor temperature <-1.5 ° C), the preheater is continuously turned on as soon as the heat exchanger starts to freeze.

The icing is detected by pressure sensors.

The supply and exhaust fan continues to run with equal amounts of air.

Only when the power of the pre-heating is not sufficient for de-icing, is also lowered over the control of the supply fan stepless until shutdown.



4.4 Version

The CWL-300/400 Excellent is equipped with 2 connectors (X14 & X15) with connection options for various applications.

The 9-pole connector X15 is accessible at the rear of the CWL-300/400 Excellent display cover without having to open the appliance.

The 2-pole connector X14 is accessible after taking off the display cover. The display cover has a second gland. That makes it possible to feed a 230 volt cable, which may be connected to connector X14, from outside the appliance.

See § 11.1 for more information on the connection possibilities of connectors X14 and X15.



5.1 Installation general

Installing the appliance

1. Placing the appliance (§5.2)
2. Connecting the condensate discharge (§5.3)
3. Connecting the ducts (§5.4)
4. Electric connection
 - Connecting the mains power (§ 5.5.1), multiple switch (§ 5.5.2) and, if necessary, the Ebus coupler (§ 5.5.3).

Installation must take place under:

- Quality requirements ventilation systems dwellings.
- The safety regulations for low-voltage installations.
- The regulations for ventilation of dwellings and residential buildings.
- Any additional regulations of the local utilities.
- The installation instructions.

5.2 Placing the appliance

The CWL-300/400 Excellent can directly be mounted to the wall using the suspension brackets supplied for that purpose. For a vibration-free result the appliance must be mounted to a solid wall with a minimum mass of 200 kg/m². A gypsum block or metal stud wall does not suffice! Additional measures such as double panelling or extra studs are required in that case. On request, a mounting support for floor mounting is available (only 4/0 version). In addition, the following aspects must be taken into account.

- The appliance must be placed level.
- The installation room must be such that a good condensate discharge with air trap and pitch for condensate can be made.
- The installation room must be frost-free.
- Make sure there is a free space of at least 70 cm at the front of the appliance and a free headroom of 1.8 m for cleaning the filters and carrying out maintenance.
- Make sure there is a free space of at least 20 cm above the display cover so it can always be removed.


5.3 Connecting the condensate discharge

The condensate discharge line for the CWL-300/400 Excellent is fed through the lower panel. The condensate must be discharged through a drainpipe.

The condensate discharge comes separately with the appliance and the installer must screw it into the underside of the appliance. This condensate discharge connection has an external connecting diameter of 32 mm.

The condensate discharge line can be glued to it, if necessary using a square bend. The installer can glue the condensate discharge in the desired position in the lower part of the appliance. The drain must discharge under the water level in the U-trap

Before connecting the condensate discharge to the appliance, pour water into the U-trap to create an air trap.



5.4 Connecting ducts


The air extract duct does not have to be fitted with a control valve. The appliance itself controls the air flow rates.

To prevent condensation on the outside of the outdoor air supply duct and the air extract duct from the CWL-300/400 Excellent, these ducts must be provided with an external vapour barrier as far as the appliance. If synthetic (EPE) pipe is used here, additional insulation is not necessary.

For optimum fan noise damping, it is recommended to use acoustic ducts with a length of 1.5 m between the appliance and the ducts from and to the dwelling.


Pay attention to crosstalk and installation noise, also for incorporated ducts. Design the duct with separate branches to the valves to prevent crosstalk. If necessary, the supply ducts must be insulated, for instance when they are installed outside the insulated envelope.

A duct diameter of 180 mm is required for the CWL-400 Excellent, for the CWL-300 Excellent can suffice with a duct diameter of 160 mm.



- 1 = CWL-300/400 Excellent left-handed 2/2 (place level)
- 2 = Preferred ventilation air supply
- 3 = Ventilation air supply under the tiles
- 4a = Free suction bottom roof area
- 4b = Free suction top roof area
- 5 = Sewer vent
- 6 = Preferred location extract ventilation air; use insulated ventilation roof sleeve.
- 7 = Synthetic high efficiency heat recovery duct
- 8 = Condensate discharge
- 9 = Acoustic duct
- 10 = Ducts from and to dwelling

- Arrange the exterior air supply from the shadowed side of the dwelling, preferably from the wall or overhang. If the outdoor air is sucked in from under the tiles, it must be ensured that no condensation develops in the roof boarding and no water can run in. Ventilation air can be sucked in from under the tiles if air can access freely at the top and the bottom of the roof area and the sewage vent stack does not end under the tiles.



- A = Spacing 10 mm above roof deck
- B = Roof insulation
- C = Seal with foam
- D = Pipe for make-up air to be carefully insulated and provided with vapour barrier

- Feed the extract duct through the roof boarding in such a manner that no condensation develops in the roof boarding.
- Install the extract duct between the CWL-300/400 Excellent and the roof sleeve in such a manner that surface condensation is prevented.
- Always use an insulated ventilation roof sleeve.
- The maximum permissible resistance in the duct system is 150 Pa at the maximum ventilation capacity. If the resistance of the duct system is higher, the maximum ventilation capacity will be lower.
- The location of the mechanical ventilation output and the sewer stack vent relative must be chosen to prevent nuisance
- Choose the location of the supply valves to prevent fouling and draught.

Install sufficient overflow openings, door gap 2 cm.

5.5 Electric connections

5.5.1 Connecting the power plug

The appliance can be connected to an easily accessible, earthed wall socket with the plug that is mounted to the appliance. The electric installation must comply with the requirements of your power company.

Make allowance for the 1000 W preheater.



Warning

The fans and control board carry a high voltage. Always take the voltage from the appliance by pulling the power plug when working on the appliance.


5.5.2 Connecting the multiple switch

The multiple switch (not supplied with the appliance) is connected to the modular connector type RJ12 (connector X2) that is placed at the rear of the appliance's display cover.

- Application of a 4-way switch with filter indication in all cases requires an RJ12 plug in combination with a 6-core modular cable.

Refer to diagrams §11.2.1 to §11.2.4 for connection examples multiple switch.

Other options include wireless remote control or a combination of multiple switches




5.5.3 Connecting eBus connector


The CWL-300/400 Excellent works with the eBUS protocol. To connect a eBUS connection, there is the 2-pin connector X1 on the rear side of the display cover.

The eBus protocol can for instance be used for coupling (cascade control) appliances (see §11.3). Because of polarity sensitivity, always connect contacts X1-1 to X1-1 and contacts X1-2 to X1-2 ; the appliance will not work when these contacts are interchanged!

Control unit BML Excellent (eBus)



- Control unit BML Excellent eBus:**
- program Day
 - program weeks
 - with eBUS interface (master)
 - Adjustable fan speeds
 - Setting the parameters of the device



6.1 General explanation control panel

The LCD display shows what the operating situation of the appliance is. Four control keys can be used to call up and modify settings in the control unit program.

When the mains power to the CWL-300/400 Excellent is switched on, all display symbols will appear during 2 seconds; at the same time the blue backlight is switched on for 60 seconds..

When one of the control keys is operated, the display will light up during 30 seconds.


When no keys are operated or when no deviating situation has developed (such as a blocking fault) the display will show the **operating mode** (see § 6.2).

After operating the key 'Menu', the keys "+" or "-" can be used to select from three different menus, including:

- **Settings menu** (SET); see § 6.3
- **Readout menu** (READ), see § 6.4
- **Service menu** (SERV), see § 6.5

Press the R key to leave any menu and return to operating mode.

Briefly press the R key (shorter than 5 seconds) to switch on the display backlight without changing anything in the menu.




A = LCD
 B = 4 control keys
 C = service connector

Key	Function key
Menu	Activate the settings menu; to the next step in the submenu; confirm value change
-	Scroll; modify value; Switching on or off the CWL-300/400 Excellent from operating mode (the press for 5 seconds)
+	Scroll; modify value
R	One step back in menu; cancel value modification; filter reset (the press for 5 seconds), delete fault history

6.2 Operating mode


In operating mode the display may simultaneously show 4 different situations/values.

- 1 = **Status fan situation**, image coupled appliances (see § 6.2.1)
- 2 = **Air flow rate** (see § 6.2.2)
- 3 = **Message text** e.g. text filter situation, activation external switch contact etc. (see § 6.2.3)
- 4 = **Fault symbol** (see § 8.1 and § 8.2)



6.2.1 Status system fan

This part of the display shows a fan together with a number. When the supply and extract fans are running, the fan symbol is displayed. When the fans are stopped, the fan symbol is not visible. The number behind the fan symbol indicates the fan situation. Refer to the table below for an explanation of the numbers.




Status fan situation on display	Description
	The supply and extract fans are running at 50 m³/h or are inactive. This situation depends on setting parameter 1 (see Chapter 13)
	The supply and extract fans are running under mode 1 of the multiple switch. Air flow rate depends on setting parameter 2 (see chapter 13).
	The supply and extract fans are running under mode 2 of the multiple switch. Air flow rate depends on setting parameter 3 (see chapter 13).
	The supply and extract fans are running under mode 3 of the multiple switch. Air flow rate depends on setting parameter 4 (see chapter 13).
	This CWL-300/400 Excellent is coupled with the aid of eBus. The supply and extract fans of the CWL-300/400 Excellent are running under switched mode of the ventilation mode "master" CWL-300/400 Excellent in addition, (only for cascade connection) the display shows the "slave" number of the relevant CWL-300/400 Excellent. Air flow rate depends on the set parameters "master" CWL-300/400 Excellent.

6.2.2 Display air flow rate

This shows the set air flow rate of the supply of extract fan. When when the air flow rates of the supply and extract fans differ, for instance when using an external switch contact, in all cases the highest air flow rate is shown.


When the appliance is switched off through software, the text "OFF" appears here.



6.2.3 Message text for operating mode

This part of the display may show a message text. The message text "Filter" always takes precedence over the other message texts.

The following message text may appear during operating mode.



Message text on display	Description	
FILTER	When the text "FILTER" appears on the display, the filter must be cleaned or replaced; for detailed information, see § 9.1	
Slave 1, Slave 2 usw.	For coupled appliances the message text shelves which appliances "Slave 1" - "Slave 9"; for detailed information, see §11.3. The "Master" appliance displays the regular image regarding ventilation mode.	<div style="text-align: center;"> <p>Master - appliance</p> <p>Slave - appliance</p> </div>
EWT	When the text "EWT" appears on the display, the geo heat exchanger is active. For extensive information, also see §11.5.	
CN1 oder CN2	When the text "CN1 or CN2" appears on the display, one of the external switch inputs is active, also see §11.6.	
V1 oder V2	When the text "VN1 or VN2" appears on the display, one of the external 0 - 10 V inputs is active, also see §11.7.	

6.3 Settings menu

For optimum performance of the appliance, set values can be modified in the settings menu to adjust the appliance to the installation situation; refer to chapter 13 for a list of the set values. A number of set values, such as the air flow rates, are laid down in the design data.

Warning:


Incorrect settings may seriously affect the proper performance of the appliance!

Modifying the set value in the settings menu:

1. In operating mode, press the 'MENU' key.



1x




2. Press the 'Menu' key to activate the "settings menu".



Settings menu is active

2x

3. Select the set value to be modified with the '+' or '-' key.




Selection setting value to be modified .

4. Press the 'Menu' key to select the required set value.



1x

5. Use keys '-' and '+' key to modify selected set value.



6. Store modified set value



1x

Store modified set value


Do not store modified set value



Modified value Do not store

1x

7. To modify other set values, repeat step 3 - 6. When you do not want to modify any more set values and return to operating situation, then press the 'R' key.



Back to operating mode


6.4 Readout menu

The readout menu can be used to call up a number of current sensor values to obtain more information on the appliance's performance. Modifying values of settings is **not** possible in the readout menu. The **readout menu** can be displayed as follows.

1. In operating mode, press the 'MENU' key. Now the display shows the **settings menu**.




Operating mode




Settings menu

2. Use the '+' and the '-' key to go to the **readout menu**.



Readout menu


3. Activate the **readout menu**.



Readout value

Step no. readout value;
refer to the table below
for an explanation

4. Use the '+' and the '-' key to scroll through the rear menu.



5. Press the 'R' key twice to go back to operating mode. If no key is operated during 5 minutes, the appliance automatically returns to operating mode.



Operating mode

2x

Step no. readout value	Description readout value	Unit
01	Current temperature from dwelling	°C
02	Current temperature outdoors sensor	°C
03	Bypass status (ON = bypass valve open, OFF = bypass valve closed)	
04	Status frost protection (ON = frost protection active, OFF = frost protection not active)	
05	Current channel pressure supply	Pa
06	Current duct pressure extract	Pa
07	Current air flow rate supply fan	m ³ /h
08	Current air flow rate extract fan	m ³ /h
09	Actual relative humidity	%

6.5 Service menu

The service menu shows the most recent 10 fault messages.


In the event of a locking fault, the settings menu and the readout menu are blocked and only the service menu can be opened; Pressing the 'menu' key directly opens the service menu.

The **service menu** can be displayed as follows.

1. In operating mode, press the 'MENU'- key. The display now shows the settings menu.




Operating mode




Settings menu

2. Use the '+' and the '-' key to go to the **service menu**.




Service menu

3. Activate the **service menu**.



4. Use the '+' and the '-' key to scroll through the messages in the service menu.




- Display not any fault message.




- Current fault message (spanner on display).



-- Unsolved fault message (no spanner on display).



5. Press the 'R' key twice to go back to operating mode. If no key is operated during 5 minutes, the appliance automatically returns to operating mode.



Operating mode

All fault messages can be deleted by pressing the "R" key in the service menu during 5 seconds; This is only possible when there is no active fault!


7.1 Switching the appliance on and off

There are two methods to switch the appliance on or off.


- Switching on and off by inserting or pulling the power plug.
- Switching on and off through software on the appliance display.

Switching on

- Switching on the mains power.
Connect the 230 V power plug to the electric system.



All display symbols appear during 2 seconds.




2 s

The software version appears during 2 seconds.



2 s


Directly after that the CWL-300/400 Excellent will be running in the mode is set on the multiple switch. If no multiple switch is connected, the appliance will always run in mode 1.



- Switching on through software
When the CWL-300/400 Excellent switched off through software, the display will show the text "OFF".




The appliance can be switched on by pressing the key '-' during 5 seconds.



> 5 s



Switching off:

- Switching off through software
Press the "-" key for 5 sec. to switch off the appliance through software. The text 'OFF' appears on the display.



> 5 s

- Switching off the mains power ;
Pull the 230 V mains plug from the mains to take the voltage from the appliance.
Nothing is shown on the display now.



Warning



When working on the appliance, always take the voltage from the appliance by first switching it off through software and subsequently pulling the power plug.

7.2 Setting the air flow rate

The factory supplies the CWL-300/400 Excellent for the CWL-Excellent 300 flow rates set to 50, 100, 150 and 225 m³/h and for the CWL-Excellent 400 set to 50, 100, 200 and 300 m³/h respectively. The performance and the energy consumption of the CWL-300/400 Excellent depend on the pressure drop in the duct system as well as on the filter resistance.

Important:

Mode 5: is 0 or 50 m³/h (not in combination with a 3-way switch).

Mode 1: must always be lower than mode 2.

Mode 2: must always be lower than mode 3;

Mode 3: CWL-300 Excellent - adjustable between 50 and 300 m³/h;
 CWL-400 Excellent- adjustable between 50 and 400 m³/h;

If these conditions are not complied with, the air flow rate of the higher mode will automatically be adjusted.

See the settings menu, §6.3, for changing the flow rates.

7.3 Other settings installer


Various other settings of the CWL-300/400 Excellent can also be modified.

How to modify these is explained in §6.3.

7.4 Factory setting

It is possible to reset all modified settings back to factory setting in one go.

All modified settings will be at the values they had when the CWL-300/400 Excellent was supplied from the factory; all message codes / fault codes will be erased from the service menu as well. The filter notification process will not reset.




8.1 Trouble shooting

When the appliance control system detects a fault, it is indicated on the display with a spanner symbol, possibly together with a fault code.

The appliance makes a distinction between a fault at which the appliance keeps running (limitedly) and a serious (locking) fault at which both fans are switched off.

In case of locking fault, the settings and readings menu is switched off as well and only the service menu is available.

The appliance remains in this fault mode until the problem in question has been solved. Then the appliance will reset itself (auto reset) and the display will once more show the operational mode.



The fans are controlled on the basis of the value of the pressure sensors mounted on the control board. For each fan 2 pressure hoses run to the control board. If these hoses are not connected as prescribed, or if they are leaking or blocked, a wrong pressure will be measured so the fans can no longer be controlled correctly. In case of doubt on the correct performance of the appliance, check the pressure hose connections


Fault E999

If, when the appliance is powered up directly to message **E999** appears on the display, the mounted control board is not suitable for this appliance or the dip switches on the control board are set incorrectly.


For the location of the dip switches see § 10.2; position M



In that case, check whether the dip switches on the control board are set as shown in the drawing of the dip switches settings; if they are, and the message E999 still appears, then replace the control board by a board of the correct type.



CWL-300 Excellent




CWL-400 Excellent

8.2 Display codes


Non-locking fault

When the appliance detects a non-locking fault, it will still keep running (limitedly). The display does show the fault symbol (spanner).



Locking fault

When the appliance detects a locking fault, it will no longer work. The (permanently lighted) display shows the fault symbol (spanner) together with fault code. The red LED on the multiple switch (if applicable) will be blinking. Contact the installer to remedy this fault. A locking fault cannot be remedied by taking the voltage from the appliance; first the fault must be solved.



Fault code	Cause	Action appliance	Action installer
E100 <small>(non-locking fault)</small>	Pressure sensor supply fan defective. Red pressure hoses blocked or "kinked".	<ul style="list-style-type: none"> - Switches to constant rpm control. - The preheater switches on at outdoor temperatures below 0°C. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Check the red pressure hoses (and pressure tubes) for fouling, kinking and damage.
E101 <small>(non-locking fault)</small>	Pressure sensor extract fan defective. Blue pressure hoses blocked or "kinked".	<ul style="list-style-type: none"> - Switches to constant rpm control. - The preheater switches on at outdoor temperatures below 0°C. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Check blue pressure hoses (and pressure tubes) for fouling, kinking and damage.
E103 <small>(non-locking fault)</small>	Bypass fault .	<ul style="list-style-type: none"> - None. (Current too low → stepper motor not correctly connected or effective; Current too high → short-circuit in wiring or stepper motor). 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Check connection stepper motor; replace wiring or stepper motor.
E104 <small>(locking fault)</small>	Extract fan defective.	<ul style="list-style-type: none"> - Both fans are switched off. - Preheater(s) is switched off. - If applicable: Postheater(s) is switched off. - Restart every 5 minutes. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Replace extract fan. • But voltage back on appliance; Fault will automatically be reset. • Check cabling.
E105 <small>(locking fault)</small>	Supply fan defective.	<ul style="list-style-type: none"> - Both fans are switched off. - Preheater(s) is switched off. - If applicable: Postheater(s) is switched off. - Restart every 5 minutes. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Replace. • Put voltage back on appliance; Fault will automatically be reset. • Check cabling.
E106 <small>(locking fault)</small>	The temperature sensor that measures the outdoor temperature is defective. .	<ul style="list-style-type: none"> - Both fans are switched off. - Preheater(s) is switched off. - Bypass closes and is blocked. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Replace temperature sensor. • Put voltage back on appliance; fault will automatically be reset.
E107 <small>(non-locking fault)</small>	The temperature sensor that measures the temperature of the extract air is defective.	<ul style="list-style-type: none"> - Bypass closes and is blocked. 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Replace indoor temperature sensor.
E108 <small>(non-locking fault)</small>	If present: The temperature sensor that measures the external temperature is defective.	<ul style="list-style-type: none"> - Postheater is switched off. - If applicable: Geo heat exchanger is switched off. 	<ul style="list-style-type: none"> • Replace external temperature sensor.
E111 <small>(non-locking fault)</small>	If present: The RH-sensor that measures the humidity is defective.	<ul style="list-style-type: none"> - Appliance continues to operate 	<ul style="list-style-type: none"> • Take the voltage from the appliance. • Replace RH-sensor.
E999 <small>(locking fault)</small>	Dip switches on control board not set correctly.	<ul style="list-style-type: none"> - Appliance does nothing; red fault LED on multiple switch is not activated either. 	<ul style="list-style-type: none"> • Put dip switches incorrect position. (see § 8.1).

Note!

If mode 2 of a multiple switch does not work, the modular connector of the multiple switch has been connected the wrong way round. Cut off one of the RJ connectors to the multiple switch and mount a new connector the other way round.

9.1. Filter cleaning


User maintenance is limited to periodically cleaning or replacing the filters. The filter only has to be cleaned when that is indicated on the display (it shows the text „FILTER”) or, if a multiple switch with filter indication is mounted, when the red LED at the switch lights up.




The filters must be replaced every year. It is not permitted to use the appliance without filters.

Cleaning or replacing the filters:


- 1 - Press the ‘-’ key for 5 seconds.
- Open the filter door.




- 2 Remove the filters. Remember in what way the filters are taken out. (Clean side of the filter in the direction of the heat exchanger).




- 3 Clean the filters.




- 4 Place the filters back the same way as they were taken out.




- 5 Close the filter door.
- Switch on the appliance by pressing the key ‘-’ during 5 seconds.



- 6 After the filters have been cleaned or replaced, press the “R” key for 5 seconds to reset the filter indication. The text “FILTER” will blink briefly to confirm that the filters have been reset. Also when the message “FILTER” has not yet appeared on the display, a filter reset can be carried out. the “counter” will be reset to zero.




After the filter reset, the text “FILTER”; disappears, the light at the multiple switch is off and the display is back to operating mode.




9.2 Maintenance

Installer maintenance includes cleaning the heat exchanger and fans. Dependent on the conditions, this must be done about once every three years.


- 1 Switch off the appliance on the control panel (Press the 'OFF' key for 5 seconds; the appliance will be switched off through software) and switch off the power. Open the filter door.




- 2 Remove the filters.




- 3 Remove the move the front cover.




- 4 Remove the heat exchanger. Be careful not to damage the foam parts in the appliance.



- 5 Rinse the exchanger with hot water (max. 55 °C) and a regular detergent. Rinse the exchanger with hot water.




- 6 Take off the display cover.
Note! First disconnect the connectors on the rear of the display cover.




7 Remove 4 pressure hoses and 3 connectors from the board.


8 Slide the fan assembly out of the appliance.



9 Place the fan assembly on a flat surface with the pressure hoses facing up. Remove the red and blue pressure hose without black mark from the pressure tubes mounted in the fan assembly. Turn over the foam assembly so the section with the pressure hoses is facing down.




10 Now the fan assembly can carefully be split so the two fans are accessible. Make sure the fans remain in the lower fan section!



11 Clean the fans with a soft brush.

Make sure the balancing weights do not shift!



12 Replace the separated part of the fan assembly and reconnect the loose pressure hoses to the pressure tubes.

Make sure no dirt enters the pressure tubes!

13 Place the complete fan assembly back into the appliance.

14 Reconnect the pressure hoses and the fan cables to the board.

Note the marking sticker on the pressure sensor for the correct position of the pressure hoses.

Refer to the sticker in the appliance for the correct position of the connectors.

15 Remount the display cover and reconnect the loose connectors on the rear of the display cover.

16 Place the heat exchanger back into the appliance.

17 Place the front cover.

18 Place the filters back into the appliance with the clean side facing the exchanger.


19 Close the filter door.

20 Switch on the power supply.

21 Switch on the appliance on the control panel (pres key " for 5 seconds.-").

22 After cleaning the filter or placing a new filter, reset the filter indication by pressing the key "R" for 5 seconds.

10.1 Basic diagram



A = Multiple switch

B = Preheater

C = Outdoor temperature sensor

D = Control board

E = Supply fan

F = Extract fan

G = Control panel

H = Indoor temperature sensor

J = Service connector

K = Valve motor bypass

L = Connections accessories

N = Not applicable

O = Ebus connector (polarity sensitive)
(not suitable for 230V!)

P = Postheater

Q = Output 0-10 V

R = Sensor postheater or outdoor sensor geo heat exchanger


S = 24 volt connector

T = Input 0-10 V (or make contact)

U = Make contact or input 0-10 V

Z = RH-sensor (option)





10.2 Wiring diagram



A = Connection for multiple switch
 B = Preheater
 C = Outdoor temperature sensor
 D = Control board
 E = Supply fan
 F = Extract fan

G = Control panel
 H = Indoor temperature sensor
 J = Service connector
 K = Valve motor bypass
 L = Extra connectors
 M = Dip switches for appliance selection


11.1 Connectors

<p>Connector X1</p>  <p>⚠ Not suitable for 230V!</p>	<p>eBus connector X1 Two-pole screw connector. Set ex factory as eBus connector; parameter 8 in the Settings menu (see §11.3). Only suitable for low voltage. Note: This connector is polarity-specific.</p>												
<p>Connector X2</p> 	<p>Modular connector X2 for rpm control Modular connector type RJ-12. Only suitable for low voltage</p>												
<p>Connector X14</p> 	<p>Connector X14 for connecting postheater or additional preheater Two-pole screw connector (accessible after taking off display cover). Ex factory this connector is not activated; after changing parameter 13 in the settings menu of "0" to "1" (preheater) or "2" (postheater), this connector can be used for connecting the postheater or preheater Maximum rated power is 1000W. Note: The postheater temperature sensor must also be connected to X15-7 and X15-8. Use the additionally mounted pull relief in the display cover to feed the 230 V cable to the postheater.</p>												
<p>Connector X15</p>  <p style="text-align: center;">X-15</p>	<p>Connector X15 (9-pole) for connecting special versions</p> <table border="1" data-bbox="778 1317 1482 2074"> <thead> <tr> <th>Connection</th> <th>Application</th> </tr> </thead> <tbody> <tr> <td>1 & 2 (input 1)</td> <td> <p>Stepnr. 15 = 0: normally open contact (= factory setting) §11.6)</p> <p>Stepnr. 15 = 1: 0 - 10V input 1; X15-1=GND & 15 - 2 = 0 - 10V (see §11.8)</p> <p>Stepnr. 15 = 2: normally closed contact</p> <p>Stepnr. 15 = 3: input 1/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 15 = 4: input 1/ bypas open →0V; bypass closed →12V</p> </td> </tr> <tr> <td>3 & 4 (input 2)</td> <td> <p>Stepnr. 21 = 0: normally open contact</p> <p>Stepnr. 21 = 1: 0 - 10V input (= factory setting) (see §11.8).</p> <p>Stepnr. 21 = 2: normally closed contact</p> <p>Stepnr. 21 = 3: input 2/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 21 = 4: input 2/ bypas open →0V; bypass closed →12V</p> </td> </tr> <tr> <td>5 & 6</td> <td>Conn. 24 volt , 4.5 VA max. (5 = ground , 6 = +)</td> </tr> <tr> <td>7 & 8</td> <td>Connection postheater sensor or and outdoor geo heat exchanger</td> </tr> <tr> <td>9</td> <td>Control signal valve 0 or 10 V (9 = + , 5 = ground)</td> </tr> </tbody> </table>	Connection	Application	1 & 2 (input 1)	<p>Stepnr. 15 = 0: normally open contact (= factory setting) §11.6)</p> <p>Stepnr. 15 = 1: 0 - 10V input 1; X15-1=GND & 15 - 2 = 0 - 10V (see §11.8)</p> <p>Stepnr. 15 = 2: normally closed contact</p> <p>Stepnr. 15 = 3: input 1/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 15 = 4: input 1/ bypas open →0V; bypass closed →12V</p>	3 & 4 (input 2)	<p>Stepnr. 21 = 0: normally open contact</p> <p>Stepnr. 21 = 1: 0 - 10V input (= factory setting) (see §11.8).</p> <p>Stepnr. 21 = 2: normally closed contact</p> <p>Stepnr. 21 = 3: input 2/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 21 = 4: input 2/ bypas open →0V; bypass closed →12V</p>	5 & 6	Conn. 24 volt , 4.5 VA max. (5 = ground , 6 = +)	7 & 8	Connection postheater sensor or and outdoor geo heat exchanger	9	Control signal valve 0 or 10 V (9 = + , 5 = ground)
Connection	Application												
1 & 2 (input 1)	<p>Stepnr. 15 = 0: normally open contact (= factory setting) §11.6)</p> <p>Stepnr. 15 = 1: 0 - 10V input 1; X15-1=GND & 15 - 2 = 0 - 10V (see §11.8)</p> <p>Stepnr. 15 = 2: normally closed contact</p> <p>Stepnr. 15 = 3: input 1/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 15 = 4: input 1/ bypas open →0V; bypass closed →12V</p>												
3 & 4 (input 2)	<p>Stepnr. 21 = 0: normally open contact</p> <p>Stepnr. 21 = 1: 0 - 10V input (= factory setting) (see §11.8).</p> <p>Stepnr. 21 = 2: normally closed contact</p> <p>Stepnr. 21 = 3: input 2/ bypas open →12V; bypass closed →0V</p> <p>Stepnr. 21 = 4: input 2/ bypas open →0V; bypass closed →12V</p>												
5 & 6	Conn. 24 volt , 4.5 VA max. (5 = ground , 6 = +)												
7 & 8	Connection postheater sensor or and outdoor geo heat exchanger												
9	Control signal valve 0 or 10 V (9 = + , 5 = ground)												

11.2 Connection examples multiple switch


A multiple switch can be connected to the modular connector X2 of the CWL-300/400 Excellent. This modular connector X2 is directly accessible at the rear of the display cover (see §11.1) without having to take it off.

11.2.1 Multiple switch with filter indication




A = CWL-300/400 Excellent
B = Multiple switch with filter indication

11.2.2 Wireless remote control (without filter indication)




A = CWL-300/400 Excellent
B = Receiver for wireless remote control
C = Transmitter with 4 settings (e.g. kitchen)
D = Any additional 4-setting transmitters (A maximum of 6 transmitters can be signed on to 1 receiver)

11.2.3 Additional multiple switch with filter indication



A = CWL-300/400 Excellent
B1 = Multiple switch with filter indication
B2 = Additional multiple switch with filter indication
C = Splitter

11.2.4 Additional multiple switch with wireless remote control




A = CWL-300/400 Excellent
B = Multiple switch with filter indication
C = Receiver for wireless remote control
D = Transmitter with 2 settings
E = Splitter

11.3 Couple CWL-300/400 Excellent through eBus contact; all appliances equal air flow rate

Important:



Because of polarity sensitivity, always connect contacts X1-1 to X1-1 and contacts X1-2 to X1-2. Never connect X1-1 and X1-2.



For M (Master):
Set parameter 9 to 0 (= factory setting).
Display shows ventilation mode 1, 2 or 3.

For C1 (Slave1):
set parameter 9 to 1 (= Slave 1).
Display always shows ventilation mode □.

For C2 (Slave2):
Set parameter 9 to 2 (= Slave 2).
Display always shows ventilation mode □.


- A = Multiple switch
- B = 2-pole connector
- M = CWL-300/400 Excellent (Master)
- C1 t/m C* = CWL-300/400 Excellent (Slave); couple not more than 10 appliances through Ebus

All CWL-appliances have the same air flow rates as the CWL-300/400 set as "Master".

Step nr.	Description	Factory setting	Range
8	Communication type	eBus	0t (= Opentherm) eBus
9	eBus address	0	0 = master 1- 9 = slave 1 - 9


11.4 Wiring diagram postheater connection or extra preheater

The electrical connections of the postheater and the extra preheater are the same; the only difference is that the postheater has an additional temperature sensor that must be wired to connector X15. Please refer to the mounting instructions that came with the heater for more extensive information regarding installation of the postheater or the extra preheater.




C1	brown
C2	blue
C3	green/yellow
C4	black

A	CWL-300/400 Excellent
B	Control board
C	Heating coil max. 1000 W
D	Maximum safety with manual reset
E	LED maximum safety; lights up when activated
F	Cables to be connected through the heater
G	Flow direction through the heater




I =		To dwelling
II =		To atmosphere
III =		From dwelling
IV =		From atmosphere

Step nr.	Description	Factory setting	Range
13	Heater	0	0 = Off 1 = Preheater 2 = Postheater



C1	brown
C2	blue
C3	green/yellow
C4	black
C5	white

A	CWL-300/400 Excellent
B	Control board
C	Heating coil max. 1000 W
D	Temperatursensor
E	Maximum safety with manual reset
F	LED maximum safety; lights up when activated
G	Cables to be connected by installer
H	Flow direction through the heater



I =		To dwelling
II =		To atmosphere
III =		From dwelling
IV =		From atmosphere

Stepnr.	Description	Factory setting	Range
13	Heater	0	0 = Off 1 = Preheater 2 = Postheater
14	Temp. postheater	21°C	15°C - 30°C


11.5 Connection example geo heat exchanger

An den CWL-300/400 Excellent kann ein Erdwärmetauscher angeschlossen werden.


Der Erdwärmetauscher kann an den Anschluss Nr. 5 (GND) und Nr. 9 (+) des 9-poligen Steckers X15 angeschlossen werden. Dieser 9-polige Stecker ist direkt an der Hinterseite der Displayhaube erreichbar, ohne dass die Displayhaube demontiert werden muss.

Beim Anschluss des Erdwärmetauschers ist es nicht mehr möglich, ein Nachheizregister an den CWL-300/400 anzuschließen!

PRINCIPLE OF GEO HEAT EXCHANGER



CONNECTION DIAGRAM OF GEO HEAT EXCHANGER




When using a geo heat exchanger, parameter 27 must be changed from "OFF" to "ON". When the air is routed through the geo heat exchanger, the CWL-300/400 Excellent display shows the text "EWT".

Step no.	Description	Factory setting	Range
27	Switching on geo heat exchanger	OFF	ON =Switched on OFF =Switched off
28	Minimum temperature geo heat exchanger	5°C	0 - 10°C
29	Maximum temperature geo heat exchanger	25°C	15 - 40°C

11.6 Connecting external switch contact

An external switch contact (e.g. switch or relay contact) can be connected to the CWL-300/400 Excellent. This external switch contact can be connected to connections no. 1 and no. 2 of 9-pole connector X15; this 9-pole connector is directly accessible at the rear of the top without having to dismount the display cover (see also §11.1).

If a second input is required as external switch contact, if necessary connections no. 3 and no. 4 of the 9-pole connector X15, which as standard are preprogrammed as 0-10 volt input, can be reprogrammed as second input switch contact. Changing parameter 21 from "0" to "1" will turn this 0-10 V input into an input make contact. When using two switch inputs, switch contact 1 (X15-1 & X15-2) always takes priority over switch contact 2 (X15-3 & X15-4).



- A = CWL-300/400 Excellent
- B = Control board
- C = Contact connected to switch input 1; for instance a switch or a relay contact
- D = Display CWL-300/400 Excellent (text "CN1" appears when contact C is closed.)

Modifying parameter 18 enables, when closing the input external switch contact 1 X15-1 and X15-2, five different situations for the extract fan to be set; dependent on the setting of parameters 19 and 20, the supply and extract fans can run at various flow rates (highest flow rate is shown on the display).

Setting Parameter 18	Function conditions	Situation supply fan extract fan	Setting parameters 19 and 20	Action supply or extract fan when closing contact inputs X15-1 & X15-2
0 (factory setting)	Contact input 1 15-1 & X15-2 closed	No action possible because contact input 1 has not been activated yet (parameter 18 is still at 0)		
1	Contact input 1 15-1 & X15-2 closed	Action dependent on setting supply fan (parameter 19) and extract fan (parameter 20)	0	Fan switches off
2	Contact input 1 15-1 & X15-2 closed Satisfies bypass conditions for valve open ¹		1	Fan minimum flow rate (50m ³ /h)
3	Contact input 1 15-1 & X15-2 closed	The bypass valve opens ¹ ; automatic bypass control in CWL-300/400 Excellent is overruled; action fans dependent on parameters 19 & 20.	2	Fan to flow rate mode 1
			3	Fan to flow rate mode 2
			4	Fan to flow rate mode 3
4	Contact input 1 15-1 & X15-2 closed	The bedroom valves ² opens. Bedroom valve 24 volt is connected to X15-5 (24V GND) X15-6 (24V +) and X15-9 (0-10 V control); action fans dependent on parameters 19 & 20.	5	Fan to flow rate multiple switch
			6	Fan to maximum flow rate
			7	No fan activation

¹) Bypass conditions opening valve:

- outdoor temperature is higher than 10°C
- temperature from atmosphere is at least lower than temperature from dwelling
- temperature from dwelling is higher than the preset bypass temperature (parameter 5)


²) Not in the delivery program

When connections X15-3 and X15-4 are programmed as switch input 2, parameters 24, 25 and 26 can be used to set the various situations the same as for contact input 1. When closing contact input 2, the display shows the text "CN2".

11.7 Connection to 0-10 V input

The CWL-300/400 Excellent can be equipped with an external provision with 0-10 volt control) (e.g. humidity sensor or CO₂ sensor). This external provision can be connected to pins no. 3 and no. 4 of 9-pole connector X15; this 9-pole connector is directly accessible at the rear of the top without having to dismount the display cover (see also §11.1).

Connections X15-3 and X15-4 are set as standard as 0 - 10 V input; it is activated as standard. Parameter 21 is set "1" ex factory. When the connected provision is active, the display shows the message V2. The minimum and maximum voltage for connected provisions can be set between 0 and 10 volt with parameter 22 (minimum voltage) and 23 (maximum voltage). The minimum voltage for parameter 22 cannot be set higher than the voltage set for parameter 23; the maximum voltage for parameter 23 cannot be set higher than the voltage set for parameter 22.




If a second 0-10 V input is required, if necessary connections no. 1 and no. 2 of the 9-pole connector X15, standard preprogrammed as switch contact, can be reprogrammed to a second input 0-10 V. Modifying parameter 15 from "0" to "1" makes this input into a proportional 0-10 V input. When using two 0 - 10 V inputs, the 0 - 10 V input with the highest flow rate always takes precedence.

Ex factory activated 0 - 10 V input (when active, the display shows the text "V2")				
Connection	Parameter	Description	Adjusting range	Factory setting
X15-3 & X15-4	21	do/ do not activate 0 - 10 V input	1 = Switched on 0 = Switched off	1
	22	minimum voltage 0 - 10 volt	0.0 volt - 10.0 volt	0.0 volt
	23	maximum voltage 0 - 10 volt	0.0 volt - 10.0 volt	10.0 volt

If connection X15-1 and X15-2 are programmed as second 0-10 V input, parameters 15, 16 and 17 can be used to modify the various situations the same as for the standard 0-10 V input. When the provision is active on the optional second 0-10 V input, the display shows the text "V1".

11.8 Connection RH (humidity) - sensor




- A = CWL-300/400 Excellent
- B = Control board
- C = RH (humidity) - sensor
- D = Cable supplied with RH sensor
- E = Duct from dwelling ↑

- C1 = brown
- C2 = blue
- C3 = green/yellow

Step nr.	Description	Factory setting	Range
30	Activating RH-sensor	OFF	OFF = not active ON = active
31	Sensitivity	0	+2 most sensitive +1 ↑ 0 default setting RH-sensor -1 ↓ -2 least sensitive

12.1 Exploded view



* Temperature sensor resistance table NTC 10k

-20°C = 96358Ω	11°C = 19037Ω	16°C = 15056Ω	21°C = 11990Ω	26°C = 9612Ω	35°C = 6535Ω	60°C = 2490Ω
-10°C = 55046Ω	12°C = 18202Ω	17°C = 14414Ω	22°C = 11493Ω	27°C = 9224Ω	40°C = 5330Ω	70°C = 1753Ω
0°C = 32554Ω	13°C = 17368Ω	18°C = 13772Ω	23°C = 10995Ω	28°C = 8835Ω	45°C = 4372Ω	80°C = 1256Ω
5°C = 25339Ω	14°C = 16533Ω	19°C = 13130Ω	24°C = 10498Ω	29°C = 8447Ω	50°C = 3605Ω	90°C = 915Ω
10°C = 19872Ω	15°C = 15698Ω	20°C = 12488Ω	25°C = 10000Ω	30°C = 8059Ω	55°C = 2989Ω	100°C = 677Ω

Modifications reserved

Wolf GmbH continuously strives after improvement of products and reserves the right to change the specifications without prior notice.

No.	Article description	Article code
1	Filter kit 2x G4 filter (standard version)	1669013
	Filter kit 1x G4 & 1x F7	1669014
2	Fan CWL-300 /400 Excellent (1 pcs)	2137965
3	Temperature sensor	2745155
4	Control panel	2745156
5	Heat exchanger CWL-300 Excellent	2071761
	Heat exchanger CWL-400 Excellent	2071545
6	Motor bypass valve	2745157
7	Bypass valve	2745158
8	Control board (When replacing, note the correct dip switch settings; see §8.1	2745159
9	Heating coil 1000 W preheater	2745160
10	Cable with power plug 230 volt with display cover*	2745161
11	Filter door left	1800137
	Filter door right	1800138
12	Front cover right	1800139
	Front cover left	1800140

- * The mains cable has a print connector.
When replacing it, always order a replacement mains cable Wolf
To avoid dangerous situations, a damaged mains should only be replaced by a qualified person!

12.2 Notes

13. Setting values

STEP NO.	DESCRIPTION	FACTORY SETTING	ADJUSTING RANGE	STEP	DISPLAY TEXT + SYMBOLS
01	Air flow rate mode CWL-300 Exc : mode	50 m ³ /h	0 m ³ /h or 50 m ³ /h		
	Air flow rate mode CWL-400 Exc. : mode	50 m ³ /h	0 m ³ /h or 50 m ³ /h		
02	Air flow rate mode CWL-300 Exc : mode 1	100 m ³ /h	50 m ³ /h - 300 m ³ /h	5 m ³ /h	1
	Air flow rate mode WL-400 Exc. : mode 1	100 m ³ /h	50 m ³ /h - 400 m ³ /h		1
03	Air flow rate mode CWL-300 Exc : mode 2	150 m ³ /h	50 m ³ /h - 300 m ³ /h	5 m ³ /h	2
	Air flow rate mode CWL-400 Exc. : mode 2	200 m ³ /h	50 m ³ /h - 400 m ³ /h		2
04	Air flow rate mode CWL-300 Exc : mode 3	225 m ³ /h	50 m ³ /h - 300 m ³ /h	5 m ³ /h	3
	Air flow rate mode CWL-400 Exc. : mode 3	300 m ³ /h	50 m ³ /h - 400 m ³ /h		3
05	Bypass temperature	22,0 °C	15,0 °C - 35,0 °C	0,5 °C	BYPASS
06	Bypass hysteresis	2,0 °C	0,0 °C - 5,0 °C	0,5 °C	BY HYS
07	Operation bypass valve	0	0 (= Automatic) 1 (= Bypass valve closed) 2 (= Bypass valve open)		BYPASS
08	Communication	eBUS	Ot (= Opentherm) eBUS		OT/BUS
09	Bus address	0	0 - 9 (0 = Master)		BUSADR
10	Central heating + heat recover	OFF	OFF (= Central heating+heat rec. off) ON (= Central heating+heat rec. on)		CV+WTW
11	Imbalance permissible	ON	OFF (= flow rate sup. equals extract) ON (= imbalance permissible)		
12	Fixed imbalance	0 m ³ /h	-100 m ³ /h to 100 m ³ /h	1 m ³ /h	
13	Heater	0	0 (= off) 1 (= preheater) 2 (= postheater)		HEATER
14	Temperature postheater	21,0 °C	15,0 °C - 30,0 °C	0,5 °C	HEATER
15	Selection input 1	0	0 (= normally open contact) 1 (= 0 - 10V input) 2 (= normally closed contact) 3 (= input 1/ bypas open → 12V; bypass closed→ 0V) 4 (= input 1/ bypas open → 0V; bypass closed→ 12V)		V1
16	Minimum voltage input 1	0,0 V	0 Volt - 10 Volt	0,5 V	V1 MIN
17	Maximum voltage input 1	10,0 V	0 Volt - 10 Volt	0,5 V	V1 MAX
18	Conditions switching input 1	0	0 (off) 1 (on) 2 (= On if conditions bypass open satisfied) 3 (= Bypass control) 4 (= Bedroom valve)		CN1
19	Supply fan mode switching input 1	5	0 (= Input fan off) 1 (= Absolute min. flow rate 50m ³ /h) 2 (= Flow rate mode 1) 3 (= Flow rate mode 2) 4 (= Flow rate mode 3) 5 (= Multiple switch) 6 (= Maximum flow rate) 7 (= no fan activation)		CN1

13. Setting values

STEP NO.	DESCRIPTION	FACTORY SETTINGS	ADJUSTING RANGE	STEP	DISPLAY TEXT + SYMBOLS
20	Extract fan mode switching input 1	5	0 (= Extract fan off) 1 (= Absolute min. flow rate 50m ³ /h) 2 (= Flow rate mode 1) 3 (= Flow rate mode 2) 4 (= Flow rate mode 3) 5 (= Multiple switch) 6 (= Maximum flow rate) 7 (= no fan activation)		CN1
21	Selection input 2	1	0 (= normally open contact) 1 (= 0 - 10V input) 2 (= normally closed contact) 3 (= input 2/ bypass open →12V; bypass closed →0V) 4 (= input 2/ bypas open →0V; bypass closed →12V)		V2
22	Minimum voltage input 2	0,0 V	0,0 Volt - 10,0 Volt	0,5 V	V2 MIN
23	Maximum voltage input 2	10,0 V	0,0 Volt- 10,0 Volt	0,5 V	V2 MAX
24	Conditions switching input 2	0	0 (off) 1 (on) 2 (= On if conditions bypass open satisfied) 3 (= Bypass control) 4 (= Bedroom valve)		CN2
25	Supply fan mode switching input 2	5	0 (= Input fan off) 1 (= Absolute min. flow rate 50m ³ /h) 2 (= Flow rate mode 1) 3 (= Flow rate mode 2) 4 (= Flow rate mode 3) 5 (= Multiple switch) 6 (= Maximum flow rate) 7 (= No input fan activation)		CN2
26	Extract fan mode switching input 2	5	0 (= Extract fan off) 1 (= Absolute min. flow rate 50m ³ /h) 2 (= Flow rate mode 1) 3 (= Flow rate mode 2) 4 (= Flow rate mode 3) 5 (= Multiple switch) 6 (= Maximum flow rate) 7 (= No extract fan activation)		CN2
27	Geo heat exchanger	OFF	OFF (= Valve control geo heat exchanger off) ON (= Valve control geo heat exchanger on)		EWT
28	Minimum temperature geo heat exchanger (Below this temperature the valve opens.)	5,0 °C	0,0 °C - 10,0 °C	0,5 °C	EWT T-
29	Maximum temperature geo heat exchanger (Above this temperature the valve opens.)	25,0 °C	15,0 °C - 40,0 °C	0,5 °C	EWT T+
30	RH-sensor	OFF	OFF (= RH-sensor not active) ON (= RH-sensor active)		
31	Sensitivity RH-sensor	0	+2 most sensitive +1 ↑ 0 default setting RH-sensor -1 ↓ -2 least sensitive		

Productdatasheet conform Ecodesign (EU), nr. 1254/2014 (Annex IV)

Supplier:		Wolf GmbH			
Model:		CWL 300 Excellent			
Climate zone	Type of control	SEC-Value in kWh/m ² /a	Energyclass (SEC)	The annual electricity consumption (AEC) in kWh	The annual heating saved (AHS) in kWh
Average	Manual	-37,52	A	308	4403
	Clock	-38,38	A	294	4425
	1 Sensor (RH/CO ₂ /VOC)	-40,01	A	269	4469
	2 or more Sensors (RH/CO ₂ /VOC)	-42,88	A+	216	4557
Cold	Manual	-80,12	A+	845	6720
	Clock	-81,19	A+	832	6754
	1 Sensor (RH/CO ₂ /VOC)	-83,25	A+	806	6821
	2 or more Sensors (RH/CO ₂ /VOC)	-86,97	A+	753	6955
Warm	Manual	-13,12	F	263	2317
	Clock	-13,86	E	250	2329
	1 Sensor (RH/CO ₂ /VOC)	-15,24	E	224	2352
	2 or more Sensors (RH/CO ₂ /VOC)	-17,62	E	171	2398
Type of ventilation unit:		Ventilation unit with heat recovery			
Fan:		Variable speed EC fan			
Type of heat exchanger:		Recuperative plastic cross-counterflow heatexchanger			
Thermal efficiency:		86%			
Maximum flow rate:		300 m ³ /h			
Electric power input:		92 W			
Sound power level Lwa:		44 dB(A)			
Reference flow rate :		210 m ³ /h			
Reference pressure difference:		50Pa			
Specific Power Input (SEL):		0,21 W/m ³ /h			
Control factor:		1,0 in combination with manual switch			
		0,95 in combination with clock			
		0,85 in combination with 1 sensor			
		0,65 in combination with 2 or more sensors			
Leakage*:	Internal	0,8%			
	External	2,1%			
Filterwarning:		On the display of the ventilation unit / Manual switch / clock control. Attention! For optimal energy efficiency and a proper operation a regular filter inspection, cleaning or replacement is necessary.			
Internet address for Assembly instructions:		http://www.wolf-heiztechnik.de/downloads/download-center/montage-und-bediensanleitungen/			
Bypass:		Yes; 100% Bypass			

* Measurements executed by TNO according to the EN 13141-7 standard (TNO-report TNO 2013 M10230, Februari 2013)

Classification from 1 January 2016	
SEC klasse ("average climate")	SEC in kWh/m ² /a
A+ (most efficient)	SEC < -42
A	-42 ≤ SEC < -34
B	-34 ≤ SEC < -26
C	-26 ≤ SEC < -23
D	-23 ≤ SEC < -20
E	-20 ≤ SEC < -10
F	-10 ≤ SEC < 0
G (least efficient)	0 ≤ SEC

Productdatasheet conform Ecodesign (EU), nr. 1254/2014 (Annex IV)					
Supplier:		Wolf GmbH			
Model:		CWL 400 Excellent			
Climate zone	Type of control	SEC-Value in kWh/m ² /a	Energyclass (SEC)	The annual electricity consumption (AEC) in kWh	The annual heating saved (AHS) in kWh
Average	Manual	-36,26	A	346	4371
	Clock	-37,23	A	331	4395
	1 Sensor (RH/CO ₂ /VOC)	-39,06	A	301	4442
	2 or more Sensors (RH/CO ₂ /VOC)	-42,27	A+	240	4536
Cold	Manual	-78,55	A+	883	6672
	Clock	-79,75	A+	868	6708
	1 Sensor (RH/CO ₂ /VOC)	-82,04	A+	838	6780
	2 or more Sensors (RH/CO ₂ /VOC)	-86,16	A+	777	6924
Warm	Manual	-12,03	F	301	2301
	Clock	-12,87	E	286	2313
	1 Sensor (RH/CO ₂ /VOC)	-14,44	E	256	2338
	2 or more Sensors (RH/CO ₂ /VOC)	-17,13	E	195	2388
Type of ventilation unit:		Ventilation unit with heat recovery			
Fan:		Variable speed EC fan			
Type of heat exchanger:		Recuperative plastic cross-counterflow heatexchanger			
Thermal efficiency:		85%			
Maximum flow rate::		400 m ³ /h			
Electric power input:		142 W			
Sound power level Lwa:		48 dB(A)			
Reference flow rate :		280 m ³ /h			
Reference pressure difference:		50Pa			
Specific Power Input (SEL):		0,24 W/m ³ /h			
Control factor:		1,0 in combination with manual switch			
		0,95 in combination with clock			
		0,85 in combination with 1 sensor			
		0,65 in combination with 2 or more sensors			
Leakage*:	Internal	0,4%			
	External	1,3%			
Filterwarning:		On the display of the ventilation unit / Manual switch / clock control. Attention! For optimal energy efficiency and a proper operation a regular filter inspection, cleaning or replacement is necessary.			
Internet address for Assembly instructions:		http://www.wolf-heiztechnik.de/downloads/download-center/montage-und-bediensanleitungen/			
Bypass:		Yes; 100% Bypass			

* Measurements executed by TNO according to the EN 13141-7 standard (TNO-report TNO - 060 - DTM - 2013 - 01161, May 2013)

Classification from 1 January 2016	
SEC klasse ("average climate")	SEC in kWh/m ² /a
A+ (most efficient)	SEC < -42
A	-42 ≤ SEC < -34
B	-34 ≤ SEC < -26
C	-26 ≤ SEC < -23
D	-23 ≤ SEC < -20
E	-20 ≤ SEC < -10
F	-10 ≤ SEC < 0
G (least efficient)	0 ≤ SEC

DECLARATION OF CONFORMITY (according to ISO/IEC 17050-1)

Nr.: **3063041**

Manufacturers: **Wolf GmbH**

Address: **Industriestr. 1
D-84048 Mainburg**

Product: **Comfort domestic ventilation unit
with heat recovery
CWL- 300/400 Excellent**

The product described above complies with the following documents:

**DIN EN 12100 Part 1 and 2; 04/2004
DIN EN ISO 13857; 06/2008
DIN EN 349; 09/2008
EN 60335 Part 1; 02/2007
EN 60730; 06/2009
EN 61000-6-2; 02/2007
EN 61000-6-3; 03/2006
EN 61000-3-2; 03/2010
EN 61000-3-3; 06/2009**

Under the provisions of the following directives:

**2006/95/EWG (low voltage directive)
2004/108/EWG (EMC directive)
RoHS 2011/65/EU (substances directive)
2009/125/EG (EU ErP-directive)**

The product bears the CE label:



Mainburg, 24.02.11

Gerdewan Jacobs
Technical Director

Klaus Grabmaier
Product Approval

613745/B